# Product data sheet Miniature connectors



Product description

M16 IP67 female cable connector, Contacts: 4, 4.0 - 8.0 mm, shielding is not possible, crimp (Crimp contacts must be ordered separately), IP67, UL

Area Order number M16 IP67 series 423 99 5110 740 04



### You can find the component part drawing and assembly instructions on the next page.

## **Technical data**

#### **General values**

Connector design Connector locking system Termination

Wire gauge (mm)

Cable outlet Upper limit temperature Lower limit temperature Customs tariff number Packaging Unit

### **Cable data**

Approval 1

female cable connector screw crimp (Crimp contacts must be ordered separately) see crimp contacts under accessories 4.0 - 8.0 mm 100 °C - 40 °C 85366990 40

UL

## **Electrical values**

Rated current (40 °C) Rated voltage Rated impulse voltage Pollution degree Overvoltage category Insulating material group Insulation resistance EMC compliance Degree of protection Mechanical operation

### Material

Contact material

Contact body material REACH SVHC 5 A 250 V 1500 V 1 I III  $\geq 10^{10} \Omega$ shielding is not possible IP67 > 500 Mating cycles

depending on crimp contact (accessory) PBT (UL94 V-0) CAS 7439-92-1 (Lead)



# Product data sheet Miniature connectors



Product description

M16 IP67 female cable connector, Contacts: 4, 4.0 - 8.0 mm, shielding is not possible, crimp (Crimp contacts must be ordered separately), IP67, UL

Area Order number M16 IP67 series 423 99 5110 740 04



Assembly instructions / Panel cut-out		
	Crimpbereich	Kontakte
	0,14 mm <sup>2</sup> – 1,0 mm <sup>2</sup>	4 – 6 pol
	0,14 mm <sup>2</sup> – 0,75 mm <sup>2</sup>	7 + 8 pol

# Product data sheet Miniature connectors



Product description

M16 IP67 female cable connector, Contacts: 4, 4.0 - 8.0 mm, shielding is not possible, crimp (Crimp contacts must be ordered separately), IP67, UL

Area Order number M16 IP67 series 423 99 5110 740 04

### Security notices

The connector must not be connected or separated under load. Non-observance and incorrect use can result in personal injury.

The connectors are designed for use in plant, control system and electrical equipment. The end user is responsible for checking whether the connectors are suitable for use in other applications.

Connectors used in electrical circuits containing hazardous life parts must only be assembled and used by or under the supervision of persons with the requisite electrotechnical training, taking the applicable regulations and standards into account.

Connectors with degree of protection IP 67 and IP 68 are not suitable for use under water. When used outdoors, the connectors must be separately protected against corrosion. For further information about IP degrees of protection refer to 'Technical support' in the Download Centre.

The connector is not suitable for mains voltages. Please observe the pollution degrees and the overvoltage category. For further information refer to 'Technical support' in the Download Centre.

To lock the cable connector to the equipment connector, the threaded ring is tightened until it is 'finger-tight' (approx. 50 cNm).

